

Enter to Heater test mode:

- (1) Keep pressing TEST button and then reboot the machine.
- (2) When it shows "33" on display, release the button.
- (3) Press TEST button until it shows "09" on display. (09 is the test mode for Heater)
- (4) Now press FREE PLAY button to activate the mechanism.
- (5) The spin motor will run for a few seconds and then heater begins to burn.
- (6) If the spin motor didn't run or heater protecting board didn't work,
it will alarm error 09 and then stop running in order to avoid heater burn out without cooling down by spin motor running.

If you don't have a heater protecting board, please short both wires as pictured below.

